



**Important:**  
 1. Use 24VAC or 12VDC supply.  
 Do not use both at the same time !  
 2. The trimmers on the board are for factory use only and must not be touched.

} Use  
 24VAC  
 or  
 12VDC

**meitav-tec**  
 Tel: 03 962 6462  
 Fax: 03 962 6620  
 e-mail: support@meitavtec.com

Title:	<b>GHU/DUCT</b>			Print name: GHU/DUCT	Drawn: P.Rechtman
Date: 26 Apr 2007	No.	Revision	Date	Software: GHU1	Checked: A.Star
				Chksum: E244	Approved: E.Roy
				File name: GHU-DUCT_ISR.VSD	